

# COFFEE MAKER INSTRUCTIONS



## **COFFEE MAKER**

#### **OPERATING INSTRUCTIONS**

- 1. Fill coffee pot with COLD water to desired amount.
- 2. Add coffee to basket (see equivalents below).
- 3. Plug coffee pot into standard electrical outlet.
- 4. When coffee has finished brewing, remove basket. The pot will keep the coffee hot.

### **CLEANING INSTRUCTIONS**

Rinse out coffee pot and basket before returning. Never immerse coffee pot in water.

#### **BREWING TIME**

It takes approximately  $\frac{1}{2}$  to 1 hour to brew coffee in 30 to 60 cup urns – 1 hour in 90 to 100 cup urns.

Coffee equivalents

Number of Cups	Coffee Measure	
36	2 Cups	
55-60	3 ½ Cups	
90	6 Cups	

One pound of coffee is equal to approximately 4-3/4 cups of ground coffee. Remember, you are renting this equipment. Be sure you are aware of the terms of your rental contract. Always return your coffee pot clean to avoid additional cleaning charges.

Complete your event by renting: China, silver, serving trays, linen, etc.
Also purchase: Paper and/or plastic party accessories.

2350 Whitman Road Unit E Concord, CA 94518 925.934.3181 www.CMParty.com CMPartyProps