

COFFEE MAKER INSTRUCTIONS

OPERATING INSTRUCTIONS

1. Fill coffee pot with COLD water to desired amount.
2. Add coffee to basket (see equivalents below.)
3. Plug coffee pot into standard electrical outlet. **Use an outlet dedicated to the coffee maker only.** Loading another item on the outlet will not allow enough power to perk the coffee properly.
4. When coffee is finished brewing, remove basket. The pot will keep the coffee hot.

CLEANING INSTRUCTIONS

1. Rinse out coffee pot and basket before returning.
2. Do not immerse pot in water!

BREWING TIME

It takes approximately 45 minutes to brew coffee in 30-60 cup machines and 1 hour in 90-100 cup machines.

COFFEE EQUIVALENTS

Number of cups	Coffee Measure
30	2 Cups
55 to 60	3.5 cups
90	6 cups

One pound of coffee is equal to approximately 4-3/4 cups of ground coffee.



1942 Mt. Diablo Blvd. • Walnut Creek, CA 94596

www.cmparty.com 925-934-3181