


POPCORN POPPER INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE USE

1. Plug machine directly into outlet, do not use extension cords. The popper operates on standard 120 volt, 60 cycle single phase AC current.
2. Turn on all switches.
3. Before first batch, allow kettle to heat for 3-4 minutes.
4. Open oil packet along top and squeeze oil into kettle. Add the corn packet and flavoring.

Pop only 1 bag at a time. Overfilling will cause kernels to burn and not pop.

5. Close lid. Leave door open while popping.
6. Empty kettle immediately after popping stops.
7. Once kettle has finished 1st batch, continue filling oil and popcorn/flavoring to pop 5 batches which will fill warming area.
8. After every few batches, please wipe out kettle with paper towels or clean, dry cloth. This prevents excessive buildup and will lessen any smoke while popping.
9. When finished popping, turn off kettle and motor switches, close doors and popcorn will be kept warm. Repeat from step 2 when ready to pop more popcorn.
10. Before returning, simply remove all popcorn and kernels and wipe out kettle and inside unit.
Do not use any commercial cleaners.
11. Please remember to return scooper!



925-934-3181
Cmparty.com