

# RICE COOKER INSTRUCTIONS

## INSTRUCTIONS

Use plastic measuring cup for the quantity of rice desired. Pour into inner pot. Rinse rice with warm water before cooking.

Measure the quantity of water by reading the water level indicator inside the inner pot. For example, when you use 20 cups of rice, you must add the water up to the number 20 stamped on the inner pot.

Place the inner pot in the cooker. When placing the inner pot into the cooker, twist the pot gently for a proper fit. The rice will not cook evenly if the pot is not level. The outer pot must be kept clean and dry as moisture will damage the sensors.

Place the lid on the pot, plug the cord into an outlet and press down the switch. A light will indicate the switch is on.


30 cups of rice takes around 30 minutes to cook.

When cooking is completed, do not open the lid immediately. Wait 15 minutes then carefully lift the lid and do not allow the condensation formed on the lid to drip into the pot.

When the rice is cooked, the "keep warm" light will be on. The power cord may be unplugged if the cooked rice does not need to be kept warm.

## CLEANING FOR RETURN

Wipe off all food particles before return. Do not immerse or use cleaning products.



925-934-3181  
cmparty.com